

Insta-TEST®

25 Test Strips
25 Tiras de análisis
25 Languettes d'analyse

CYANURIC ACID
ÁCIDO CIANÚRICO
ACIDE CYANURIQUE

 **LaMotte**

Cyanuric Acid, Ácido Cianúrico,
Acide Cyanurique ppm



Immerse strip for 2 seconds. Remove strip with pad face up. **DO NOT SHAKE OFF EXCESS WATER.** Wait 15 seconds. Compare strip to color chart.

- Works best when pH is between 7.0 to 8.4.
- Keep wet fingers out of the bottle.
- Close cap tightly after removing strip.
- For best results read in natural daylight.
- Store in a cool dry place.

Introduir la tira en la muestra durante 2 segundos. Sacarla del agua en posición horizontal con las almohadillas hacia arriba. No sacudir el agua acumulada en la tira. Espera 15 segundos. Haga la comparación.

- Fonctionne mieux à des niveaux si le pH est > à 7.0 et < à 8.4.

Immerger la languette dans l'échantillon durant 2 secondes. La sortir de l'eau en la maintenant en position horizontale, les indicateurs sur le dessus. Ne pas secouer l'eau accumulée sur la languette. Garder le niveau de la bande pour 15 secondes. Faites les comparaisons.

- Funciona mejor con niveles de si el pH es > a 7.0 e < a 8.4.



Code 3007

Made in
USA

LaMotte Co., Chestertown, MD 21620 USA • www.lamotte.com/insta

Lot# 21910 Exp. 3/14

6 70657 56525 9

